



TV - Blau TV - Bleu TV - blauw



W	⊖	∅ mm	↑ mm	□	lm	cd	↘	K	⌚	ON/OFF	⊞	EAN	⊞
15	E14	25	60	E	20				1.000		16	4000870 810101	810.10
													2,39 2,09 1,99



300° Klar 300° Clair 300° Helder



W	⊖	∅ mm	↑ mm	□	lm	cd	↘	K	⌚	ON/OFF	⊞	EAN	⊞
15	E14	22	50	E	85			2.300	1.000		16	4000870 820100	820.10
													2,03 1,77 1,69
25	E14	25	55	E	125			2.200	1.000	4000	16	4000870 820117	820.11
													2,03 1,77 1,69



300° Klar 300° Clair 300° Helder



W	⊖	∅ mm	↑ mm	□	lm	cd	↘	K	⌚	ON/OFF	⊞	EAN	⊞
25	E14	45	75	E	185			2.300	1.000	4000	8	4000870 820209	820.20
													2,39 2,09 1,99
40	E14	45	75	E	389			2.700	1.000		8	4000870 820407	820.40
													2,39 2,09 1,99

300°/Opal 300°/Opale 300°/Opaal



W	⊖	∅ mm	↑ mm	□	lm	cd	↘	K	⌚	ON/OFF	⊞	EAN	⊞
25	E14	45	78	E	160			2.700	1.000		8	4000870 106211	106.21
													2,03 1,77 1,69
40	E14	45	78	E	300			2.700	1.000		8	4000870 106419	106.41
													2,03 1,77 1,69



Klar Clair Helder



W	⊖	∅ mm	↑ mm	□	lm	cd	↘	K	⌚	ON/OFF	⊞	EAN	⊞
15	BA15d	16	47	E	75			2.300	1.000		16	4000870 808108	808.10
													1,79 1,56 1,49